

Date 28 Jan. 2014

MISCELLANEOUS FIELD NOTES

Commonwealth Stream @ C1

- Here to close gage
- Need to re-do control
- Need to re-do box anchors
- orifice in sediment, SC probe full of sediment

#6c 1024	IG	OG	#6c 1031	OG
stage	8.46	TD=2.48	8.48	TD=2.48
WT	0.29	OG=8.445	0.54	1.0
SC	44.7		62.5	EC=22.55

- cleared orifice & SC probe

- WR @ 1045

Plume 0.356 ft @ 1045

#6c 1045

stage	8.53	TD=2.45	OG=8.475
WT	0.89		
SC	47.9		

- Retarped control @ ~1100-1145

#6c 1153	IG	OG
stage	8.78	TD=2.10ft
		OG=8.825

- ran levels

- copied program to new SM (CL-1314B)

No. _____ of _____ sheets