

Date

4 Dec 13 @ 1350

MISCELLANEOUS FIELD NOTES

f9 Green SWC

here to fix SC & WT probes.

Flow!

SC probe has extra purple & white wire ???

Fixed WT & SC wiring but only WT working now
Forgot to bring $\checkmark$ SI

IC 0.6 (TD)

Stage @ 1404 3.608 0.98'

* 6 @ 1405 1) 3.609 2) 5.22 3) 9.11 4) 2.46 5) 14.5

Will come back as soon as Helos deliver new
SC cord. no WA or Q taken.Back 5/Dec/13 around 1700 to replace
SC wire, forgot keypad.

No. _____ of _____ sheets